CORKSPO

60

CORKSPOR

CorkSport Bronze Shifter Bushings Gen-6-958-10 Mazda Performance Brand www.CorkSport.com

CORKSPORT





NOTE: The installation instructions were written while doing the installation on a 2003.5 Mazdaspeed Protégé. The procedure will be the same for your vehicle.



DANGER: Follow instructions that came with your jack/stands. Death and or significant property damage could result if you do not.



NOTE: The first part of the installation instructions are for the shifter bushings located at the CORKSPOR

	KSPORT	CORKS		CORKSPOR	CORKSP!	ORT
F	Part Number:	Model 4/47	Year	Trim		
	Gen-6-958-10 Time Estimate:	Mazda Mx6	93-96	All (Manual Transr	mission)	
	30-45 min	Ford Probe	93-97	ORN		201
	Wrench Rating: 2/5	Mazda 626	93-97	(9)	ORKA	77
ŀ	2/5	1	1201			

Tooling List:

10mm wrench or socket

Floor Jack

Torque wrench

Two jack stands

12mm socket

12mm Wrench

Parts List:

CORKSP!

Quantity (2): 10mm I.D. bronze shifter bushings

CORKSPOR Quantity (2): 12.5mm I.D. bronze shifter bushings

CORKSPORT

2 page installation instructions



CORKSPOCORKSPO www.CorkSport.com

CORKS

CORK

1. Jack up your car and place it securely on the jack stands.



S

DANGER: Follow instructions that came with your jack/stands. Death and or significant property damage could result if you do not.

2: Removing Shift linkage (transmission side).

CORKSPOK

A) Remove the 12mm headed nut, located at the shift rod to transmission, shown in Figure 2a.

B) Remove the shift linkage bolt by pulling it up and out, shown in figure 2b.





D) Remove the two plastic shifter bushings, one from the top and the other from the bottom.





3: Install New Bronze shifter bushings.

A) Install the two 10mm ID bronze shifter bushings into the transmission linkage as shown in Figure 3a, one on the top and one on the bottom. They should fit snugly, so make sure you have the 10mm not 12.5mm.

B) Install the shift linkage bolt as shown in Figure 3b.

C) Reinstall the 12mm headed nut and tighten to 12-16 ft/lbs or torque as shown in Figure 3c.



CORKSPOCORKSPO www.CorkSport.com

CORKSPO

CORKS

CORKSPOR

- O PORT CORKSPORT 4: Removing Shift linkage (Shifter side).
 - A) Remove the 12mm nut from the shifter (shown in Figure 4a on the right).

KSP

B) Remove the 12mm headed bolt from the shifter and the linkage and slide the linkage from the shifter.



C) Remove the stock plastic shifter bushings from the shifter.





- 5: Install New Bronze shifter bushings.
- A) Install the two 12.5mm ID bronze shifter bushings into the shifter (Figure 5a).
- B) Slide the shift linkage back in place at the shifter and reinstall the 12mm headed bolt (Figure 5b).

 C) Reinstall the 12mm headed bolt on to the shifter and tighten to 12-16 ft/lbs of torque (Figure 5c).



D) Lower your car to the ground from the jack stands and test the shifter. If the shifter is too difficult to tight and direct when shifting gears. move, re-check the torque specs on the 12mm headed nuts on the shift linkage. The shifter should feel CORKSPOR